



Installing Propeller to Motor Instructions

Insert prop Pin in the shaft that comes out of the motor

Slide Propeller onto the shaft. Ensure that the prop pin is nested in the slot on the propeller. Please note the propeller only fits one way.

Slide on the Washer, then the nut and securely tighten with an 11/16" socket wrench.

Replace Anodes

To maintain and protect your investment replace the anodes once a year. In addition, if the bottom of your boat and outdrive components need anti-fouling paint, we recommend coating the section of the thruster which is under the water with the same anti-fouling paint. Check that your air line is in good condition. Ensure batteries are fully charged.

Remove: grasp the anode with pliers and turn counter clockwise.

Install: install the new anode by turning it clockwise to the bottom and then give it an extra half turn

